

Customer Instructions

Airless Paint Sprayer, Electric

Warning: NEVER aim gun at any person or at yourself - severe injury will result.

WEAR EYE PROTECTION AT ALL TIMES. SOME PRODUCTS MAY REQUIRE THAT YOU WEAR A RESPIRATOR & PROTECTIVE CLOTHING.

Equipment MUST be cleaned before return. There is a charge for cleaning and/or damage.

Operating Instructions

1. Place paint sprayer as far as possible away from spraying area, to prevent unnecessary cleaning and a possible extra charge to you.
2. Plug unit into a 120V outlet. If you need to use an extension cord it must be 12 gauge or larger with a length no longer than 50'. (We rent the correct extension cord)
3. Thin (reduce) paint according to manufacturer's recommendation. Strain your paint. (We stock strainer bags-ask for them)
4. After mixing paint, place suction tube & drain hose assembly into 5 gallon paint bucket. Do not remove filter bag around the strainer.
5. Set selector valve to "priming" position - Handle pointing down. (6 o'clock position)
6. Set power switch to ON.
7. Run in priming mode until bubbles no longer appear in the paint.
8. Set selector valve to "pressure" position - Handle pointing horizontal away (9 o'clock position) from sprayer.
9. Spray at absorbent surface (cardboard, newspaper, rags, etc.) until all cleaning solution is discharged from pressure hose and gun, and your paint color is coming out of the gun.
10. Adjust pressure control counter-clockwise to the lowest setting that provides a uniform pattern (extended oval). Test on cardboard or absorbent surface.
11. Proceed with painting.
12. When done painting, a) flush entire system with water by "priming" then "spraying" until clear water is discharged; & b) clean gun & hoses with warm soapy water or thinner.
13. Use the same cleaning procedure if you have to interrupt your painting for 1/2 hr. or longer.
14. If spray tip should become clogged, release the trigger, reverse the tip and spray away from the area to be painted, through the reversed tip.
15. **DO NOT** disassemble spray gun for cleaning-it is easily damaged.
16. Please call A to Z if you experience any problems or have additional questions.



Disclaimer:

These instructions are intended as a helpful reminder. They do not replace the full operating instructions found in the owners manual, which is available at the rental counter.

A to Z Equipment Rentals & Sales - 4 locations in the Phoenix Arizona Metro Area
If you like this piece of equipment, inquire about purchasing it!

If equipment does not work properly, notify office at once - Phoenix, 602-955-5100 • North Valley., 602-992-1150 •
 • East Valley, 480-539-8700 • West Valley, 623-925-0200 •