

Customer Instructions Ground Hog Pull Trencher



Warning: Wear boots, close fitting clothing & eye protection when operating a trencher. Always keep away from the chain when the machine is operating, and keep children clear at all times. Use only unleaded fuel, and do not overfill with fuel.

Operating Instructions

1. To start the engine, turn the red switch at the front of the engine, to the “on” position. To turn on the machine, turn the toggle switch on the handle of the trencher to the “on” position. Move the black (fuel) lever towards the engine, to turn on the fuel. Move the grey (choke) lever away from the engine to start.
2. Pull the recoil rope to start the engine. When the engine has started, move the grey (choke) lever towards the engine, into the run position.
3. Grab the handles and lift up to put pressure on the digging chain, then move the depth lever to the desired depth.
4. Push down on the handles to lift the digging chain off of the ground, and move the throttle lever to full throttle, then lower the digging chain into the ground.
5. Pull the trencher along until you reach the end of the run. Move the throttle lever to the idle position, and raise the digging chain out of the trench. Continue until your job is completed. When you are finished, grab the handles and lift up to put pressure on the digging chain,
6. Shut off the engine, and move the black (fuel) lever away from the engine to make the unit ready for transport.



Disclaimer:

These instructions are intended as a helpful reminder. They do not replace the full operating instructions found in the owners manual, which is available at the rental counter.

**A to Z Equipment Rentals & Sales - 4 locations in the Phoenix Arizona Metro Area
If you like this piece of equipment, inquire about purchasing it !**

If equipment does not work properly, notify office at once -

• Phoenix, 602-955-5100 • North Valley, 602-992-1150 • East Valley, 480-539-8700 • West Valley, 623-925-0200 •