




## Customer Instructions Trailers

**WARNING - DO NOT EXCEED WEIGHT AND SPEED LIMITS  
- OBEY ALL TRAFFIC LAWS**

**CUSTOMER IS RESPONSIBLE FOR ALL ROADSIDE  
SERVICE IF TRAILER IS TAKEN OUTSIDE  
THE PHOENIX METRO AREA**

1. Do not exceed the maximum weight limits stenciled on the trailer. If in doubt about the weight of your load, ask our salesman. The total weight of trailer & load must not exceed the weight of the towing vehicle.
  2. Do not exceed 50 miles per hour when towing a trailer. Allow extra time and distance for braking, stopping, passing, merging and changing lanes. Stay in the right lane.
- SECURE ALL LOADS & COVER IF NECESSARY TO AVOID DEBRIS BLOWING TO THE STREET. MAKE WIDE TURNS TO THE RIGHT.**
3. Load the trailer with more of the weight in the front half of the trailer, and secure the load to prevent shifting. The weight on the trailer ball should be approximately 100-200 lbs.
  4. Utility trailers (see picture below) are not to be used to haul dirt, rocks, sand, sod, bricks, gravel, lumber, firewood, broken concrete, scrap iron, fuel or chemicals. We have specially designed trailers to haul some of these materials.
  5. Check the hitch installation, including safety chains, after loading the trailer. Do not disconnect the trailer from the towing vehicle.
  6. If swaying occurs, reduce speed gradually. **Don't hit your brake pedal hard.** Pull over and adjust your load so more weight is toward the front of the trailer
  7. Never allow passengers in any trailer, and never load cargo on the outside of the trailer.
  8. Use mirrors if your vision is obstructed by the trailer or the load.
  9. Be sure your trailer ball is the correct size for trailer being towed. If you have any questions, please ask your rental service person.



Disclaimer:

*These instructions are intended as a helpful reminder. They do not replace the traffic laws of the State of Arizona which must be obeyed at all times.*

**A to Z Equipment Rentals & Sales - 4 locations in the Phoenix Arizona Metro Area  
If you like this piece of equipment, inquire about purchasing it!**

If equipment does not work properly, notify office at once -

• Phoenix, 602-955-5100 • North Valley, 602-992-1150 • East Valley, 480-539-8700 • West Valley, 623-925-0200 •